

Placitas Bed Assembly Instructions

Dave Cady's NOMAD FURNITURE

Albuquerque, NM www.nomadfurniture.com 505-250-5231

Tools needed for assembly

A phillips screwdriver Rubber mallet or hammer w/block included Optional; one friend

Bed parts list

2-short legs with shoulder screws

2-long bed legs-headboard

2-crosspieces, 1 with holes

2-carved crosspieces 1 with holes

2-side rails with ledgers

1-center support (2 for King size)

1-strapped slat roll


4-5/8"shoulder screws

4-5/16"x1" wood pins (ledgers)

2-1" screws (for slats)

XTRA Bed Footboard

If ordered, 2-long leg replace short legs 1-additional crosspiece



HeadboardAssembly

- 1. If possible, go to this site for photo slides of assembly HTTP://NOMADFURNITURE.COM/BED-ASSEMBLY-GALLERY/
- 2. Identify all pieces before beginning. Lay out parts as shown in diagram.

Note: To protect the wood only use a hammer with the wood block (in shipping box as a pad) to tap down parts. Or a rubber

- 3. Attach all crosspieces to one leg, then attach to the other leg.
- Assemble headboard and footboard. For footboard USE LOWER PINS for crosspiece.

Note: When attaching crosspieces to shoulder screws on legs; the top shoulder screw should be located in the center of the crosspiece. Refer to our "CAUTION SHEET".

- Install four 5/8" shoulder screws into predrilled holes on the headboard and footboard crosspieces.
- 6. Tap down on crosspieces using rubber mallet to make sure joints are snug.
- 7. Attach headboard to footboard using the two side rails (ledger).
- 8. Attach the center support rail (it will be tight).
- 9. Tap down rails until snug.

Note: It is important that all joints are tapped down completely.

- 10. Install four 5/16"x1" wood pins in holes in the side rail ledgers.
- 11. Lay out slat roll, strap up, so that end slats overlap wood pins.

Important: Screw center slat tight to the side rail ledger using two 1" screws.

Dave Cady's Nomad Furniture Limited Warranty

Nomad Furniture guarantees all of our products to be free of defects in materials or craftsmanship. During the first 60 days most problems will be evident. Call your retailer or Nomad Furniture for return instructions and we will pay the freight. After 60 days of normal use simply return any part that is defective and we will repair or replace it at no cost to the original owner for 5 years.